

How to add camera to Blue Iris

1, RTSP to add

RTSP data for camera as below:

MAIN: rtsp://<IP>:554/11

VICE : rtsp://<IP>:554/12

Just need to choose RTSP, and then input RTSP data, then click OK

