

2. Revise camera IP address

Note: Please do not revise here when you revising the camera ip address

We don't suggest you alter the ip address by yourself.

The screenshot shows a camera configuration interface with two main sections. The top section is for DHCP settings, and the bottom section is for manual IP configuration. Red annotations highlight the DHCP checkbox and the '20' in the IP address fields.

Local IP 192.168.20.86 DHCP The software finds available network setting for the Ipcamera automatically. We suggest you just use it, you want to modify it manually WIFI Settings

IP Address	192 . 168 . 20 . 87	Name	IPCAM
SubMask	255 . 255 . 255 . 0	User	admin
GateWay	192 . 168 . 20 . 1	Password	*****
Port	80		Pwd Reset

Please do not revise here when you revising the camera ip address

IP Address	192.168.20.41	Name	IPCAM
SubMask	255.255.255.0	Port	80
GateWay	192.168.20.1		
MAC Address	08:EA:40:78:7D:69	<input checked="" type="checkbox"/> DHCP	

Click Next to confirm the selected device, click Back to reselect the device

Back Next Cancel

The equipment has been installed successfully ,you can now click on the following link to connect the remote ipcamera.

<http://192.168.20.41>

If you can not video through IE, select the IE's "Tools" menu "safe" option, the security level is selected as a minimum.

Press "Finish" button to exit the program, or press "Back" button to set another device.

Back

Next

Finish