



ご注意：

検索ツールでカメラの IP アドレスの検索が失敗する場合は、指示ランプが点灯しているかをご確認ください（カメラは有線 LAN でルーターに繋がる）。また失敗の場合、リセットボタンを 10～15 秒押し、カメラを初期化してください。

2. カメラの IP アドレスを変更する方法

ご注意： カメラの IP アドレスを変更する際に赤枠部分の数値を変更しないでください。

カメラが故障になる可能性が出ますので、お客様自分でカメラの IP アドレスを変更することはオススメません。

Local IP 192.168.20.86

DHCP

The software finds available network setting for the Ipcamera automatically. We suggest you just use it, you want to modify it manually

WIFI Settings

IP Address: 192 . 168 . 20 . 87

SubMask: 255 . 255 . 255 . 0

GateWay: 192 . 168 . 20 . 1

Port: 80

Name: IPCAM

User: admin

Password: *****

Pwd Reset

Please do not revise here when you revising the camera ip address

IP Address: 192.168.20.41

SubMask: 255.255.255.0

GateWay: 192.168.20.1

MAC Address: 08:EA:40:78:7D:69

Name: IPCAM

Port: 80

DHCP

Click Next to confirm the selected device, click Back to reselect the device

Back Next Cancel

The equipment has been installed successfully, you can now click on the following link to connect the remote ipcamera.

<http://192.168.20.41>

If you can not video through IE, select the IE's "Tools" menu "safe" option, the security level is selected as a minimum.

Press "Finish" button to exit the program, or press "Back" button to set another device.

Back Next Finish

3. WiFi の設定方法

「Wifi Settings」 ボタンをクリックし、「Search WIFI」 ボタンをクリックすると、画像のようにWiFiが表示されます。

NO.	Wifi Name	Sig...	Secury Type	Secury Mode	Channel
1	devele-LY	100	WPA2-PSK	AES	1
2	devele-LY	100	WPA2-PSK	AES	1
3	devele3	100	WPA-PSK	TKIP	6
4	devele1	100	WPA-PSK	TKIP	11
5	devele2	100	WPA-PSK	AES	11
6	TP-LINK CA16	89	WPA-PSK	AES	11
7	HUASHIWIFI	89	WPA2-PSK	TKIP	7
8	HUASHIWIFI	73	WPA2-PSK	TKIP	7
9	HUASHIWIFI	73	WPA2-PSK	TKIP	7
10	ChinaNet-N5td	68	WPA-PSK	TKIP	5
11	201888	68	WPA2-PSK	AES	6
12	111222	57	WPA2-PSK	AES	1
13	360鋒崙垂WiFi-II	57	WPA-PSK	AES	11

SSID: Safe Type: Security Mode:

Wifi Mode: Password: OnOff:

*設定失敗の場合は、IE(Interner Explorer)へログインし、Wifi の設定を試してお願いします。また失敗の場合は、お気軽に jpfswl@outlook.com までご連絡ください。