


Come aggiungere una telecamera POE a Ispy

1 Aggiungi un flusso RTSP

1.1 main stream: `rtsp://username:password@x.x.x.x/stream0`

1.2 vice stream: `rtsp://username:password@x.x.x.x/stream1`

Trova il tab “FFMPEG(H264)”, inserisci come URL l’indirizzo del flusso RTSP. Dopo averlo aggiunto testalo col pulsante “test” e poi clicca “OK” per confermare se corretto.



Vai alle opzioni “Camera”

Inserisci l’indirizzo ip della telecamera, nome utente e password, clicca “Finish” (“Finito”), e la telecamera è aggiunta (se i dati sono corretti)

Edit Camera (ID: 1, DIR: ENKDF)

Camera Motion Detection Alerts Recording PTZ Images PIP Cloud Storage Scheduling Storage

Video Source

Source Adv. Properties Inputs Options

Name

Groups [Help](#)

Camera Active Fill

Transform

Timestamp

Mask Image

Picture In Picture

Maximum Frame Rate When Recording

Microphone

Microphone None [Help](#)

Ignore Audio

Talk

Camera Model [Settings](#)

IP Address Port

Username Password

Exit this to enable alerts and recording [Copy To](#) [Help](#)